


RONSON®

Check For Sparks




Flint

Lack of sparks can be caused by one of the following:




A



No flint

See "Replacing a flint."


B



Jammed flint

See "Replacing a flint."

C



Jammed flint

Clean the flint wheel with a small brush.

