RONSON®

REPLACING A FLINT

We recommend the use of Ronson Flints with your Ronson Lighter. Other makes of flint may be the incorrect diameter for your lighter and may jam, thus rendering your guarantee void

Butane fuelled lighters with a lever spring
Lift the lid of the lighter and locate the flint spring lever

Push the lever back and lock into place

Remove any remnants of the old flint

Insert a new Ronson Flint

Release the flint spring lever

To bed in the flint ignite several times

Butane and petrol lighters with a coil spring
Locate and remove the flint spring

Remove any remnants of the old flint

Insert a new Ronson flint

Replace the flint spring and lighter cover if applicable

To bed in the flint ignite several times